



CloudGate

Quick Start Guide

OPTION NV - Gaston Geenslaan 14 - 3001 Leuven Belgium
T +32 16 317 411 - F +32 16 207 164 - www.option.com

2004011

This product complies with the essential requirements of the EMC directive 2014/30/EU and the Low Voltage directive 2014/35/EU. The Declaration of Conformity can be found in the CloudGate documentation.

<http://cloudgate.option.com>



To begin using the CloudGate, follow the steps in this guide:

1. Register your **CloudGate** to the Option provisioning server
 - Download a QR code scanner on your Smartphone.
 - Scan the QR code at the back of your device.
 - Sign in and follow the instructions.

Or

 - Go to the Option Provisioning server
 - <http://cloudgate.option.com>
 - Sign in and follow the instructions.

2. Power up the **CloudGate** by plugging in an appropriate power supply (9-33VDC) into the connector on the back of the device.

3. Connect an Ethernet cable to the **CloudGate's** Ethernet port on one end and a computer on the other end.

4. Open a web browser on the computer and enter the address **192.168.1.1** into the address bar. Enter the default username (admin) and password (admin). The window as seen above should appear. From here you can set all necessary parameters of the CloudGate.

